

SAFEMASTER PRO

Configurable safety system - Modular and multifunctional

With the size of the plants and complexity of the safety requirements the number of safety devices increases in many applications. In addition logical functions need to be implemented when e.g. only parts of the whole system needed to be disconnected. The modular and **configurable safety system SAFEMASTER PRO** of DOLD monitors the safety circuits of your machines and plants simple, flexible and safe. The number of inputs and outputs of the central control unit can be amended by extension modules. In this way SAFEMASTER PRO can be configured very flexible to the actual application.

The configuration of the TUEV approved system is done very simple on a PC with the free configuration software **SAFEMASTER PRO Designer**: Select safety functions, assign in and outputs and connect them comfortably by PC. Finally transfer the tested logic via USB cable to the safety controller. Ready!

Your advantages

- For safety applications up to Cat 4 / PL e and SIL 3
- TÜV certified hardware and software
- Configuration instead of wiring with SAFEMASTER PRO Designer
- Simple handling by Drag & Drop in the graphic programming tool
- Time and cost saving set-up
- Reduces wiring and saves space in the cabinet
- Flexible extension with safe I/O modules
- ► Safe remote I/Os with bus extender modules for longer distances
- Extensive failure localisation and diagnostics
- Memory card as option for simple maintenance

DOLD &

Our experience. Your safety.

Configurable safety system

Technical features

- Compact design: Control Unit and Extension modules only 22.5 mm width
- Max. 128 safe inputs and 16 dual-channel or 32 single-channel safety related outputs
- In addition to the Controller unit max. 14 extension modules can be connected
- Flexible safety logic to create and amend the safety functions
- Safe integrated logic testing
- Monitoring outputs, status LEDs and field bus connection to provide best diagnostic functions
- TÜV and UL approval



Now also with safe speed monitoring!

System components



Control unit

- ▶ 8 safety inputs
- ▶ 4 single-channel (/080) or 2 dual-channel safety outputs (OSSD)
- Individual programmable restart condition of the feedback circuit for each output
- Configuration via PC by Mini USB port *UG 6911.10* Art.-No. 0063818

UG 6911.12/080 Art.-No. 0068574

Input/Output modules

- ▶ 8 safety inputs
- 4 single-channel (/080) or 2 dual-channel safety outputs (OSSD)
- Individual programmable restart condition of the feedback circuit for each output UG 6916.10 Art.-No. 0063819 UG 6916.12/080 Art.-No. 0068590

Input modules

8, 12 or 16 safety inputs
UG 6913.08 Art.-No. 0063820
UG 6913.12 Art.-No. 0064865
UG 6913.16 Art.-No. 0063821

Output modules OSSD

- ▶ 2 or 4 dual-channel safety outputs (OSSD)
- Individual programmable restart condition of the feedback circuit for each output UG 6912.02 Art.-No. 0063822 UG 6912.04 Art.-No. 0063823

Output modules relay

- ▶ 1 or 2 dual-channel safety relay outputs for relay contact extension of the OSSDs UG 6912.14 Art.-No. 0063824 UG 6912.28 Art.-No. 0063825
- ▶ 4 independent single-channel safety relay outputs
- Individual programmable restart condition of the feedback circuit for each output UG 6914.04 Art.-No. 0066057

Bus Extender

Decentralization of safe inputs/outputs up to 50 m with up to 6 decentralized module groups UG 6918 Art.-No. 0064866

Fieldbus modules

Fieldbus modules (Gateways) for extensive diagnostics:

UG 6951 (CANopen) Art.-No. 0063828 UG 6952 (PROFIBUS DP) Art.-No. 0063826 UG 6954 (PROFINET) Art.-No. 0064861 Art.-No. 0064862 UG 6955 (Ethernet/IP) Art.-No. 0064863 UG 6956 (EtherCAT) Art.-No. 0064864 UG 6957 (USB) UG 6958 (Modbus TCP/IP) Art.-No. 0068268 Art.-No. 0068270 UG 6959 (Modbus RTU)








Further information

SAFEMASTER PRO



www.dold.com

Configuration instead of wiring with SAFEMASTER PRO Designer



Simple configuration in only 3 steps:

- Select and configure safety functions
- 2 Assign in- and outputs and connect them comfortably on the PC
- Test safety logic and transfer it via USB cable to the safety module ready!



E. Dold & Söhne GmbH & Co. KG Bregstraße 18 • D-78120 Furtwangen T +49 7723 654-0 • F +49 7723 654-356 dold-relays@dold.com • www.dold.com