Monitoring Technique

VARIMETER Motor Load Monitor BH 9097

Translation of the original instructions






Product Discription

The load monitor BH 9097 of the VARIMETER series reliably monitors the load of motors as well as the functionality of electrical consumers. If the load exceeds or falls below the limit values, which can be set by means of a rotary switch, the corresponding output relay is activated. To suppress short-term load fluctuations, a response delay tv can be set. LEDs indicate the switching status of the associated output relays. Early detection of impending failures and preventive maintenance prevent costly damage, and as a user you benefit from the operational safety and high availability of your system.

Function Diagram for Setting De-energized on Fault*)



P1max/P2max: Overload monitoring with prewarning P1min/P2max: Under- and overload monitoring

S1/S2 ON: Manual reset S1/S2 OFF: Automatic reset

IIII: Corresponding LED is flashing

*) when set to energized on fault the function of LEDs and output relays are inverted.

Your Advantages

- · Identification of
 - Underload P1 and Overload P2
 - Overload P1 (prewarning) and Overload P2 programmable
- Adjustment of P₁ and P₂ on absolute scale
- For motors up to 22 kW / 400 V; 37 kW / 600 V
- Large current range because of automatic range selection
- De-energized or energized on fault, programmable
- Early detection of irregularities
- Reduced wiring effort

Features

- According to IEC/EN 60255-1, IEC/EN 60255-26, DIN/VDE 0435-303
- Measurement: Effective power
- 1 changeover contact for P₁ and 1 changeover contact for P₂
- Adjustable start-up time delay ta
- Adjustable switching delay t_v
- With automatic or manual reset, programmable
- Test / Reset button for easy setup
- Up to 40 A without external current transformer
- Also for single-phase operation
- LED indicators
- Width 45 mm

Approvals and Markings



* see variants

Applications

The BH 9097 is used to monitor variable loads on industrial motors.

Function

Due to the 1-phase measuring principle, a symmetrical load of all 3 phases is assumed, as is usual with motor loads. Using DIPswitches the unit can be set up to act as under- and overload relay $P_{1\text{min}}/\,P_{2\,\text{max.}}$ or as overload relay with pre-warning $P_{1\,\text{max.}}/P_{2\,\text{max.}}$ The settings of P₁ and P₂ are absolute values and calibrated in Watts adjustable via rotational switches. 2 LEDs show the state of the corresponding output relays. The unit can be configured to energise or to de-energise on fault. Every output relay is fitted with it's own time delay t. A start-up time delay ta acts on both outputs.

Indication

During start-up time delay t Green LED, U,: Flashing:

Continuous: Supply connected

Yellow LED, P₁: Flashing: During time delay t_{v1} and for set up

assistance

When relay P₁ active (contact 11-14) Continuous: Yellow LED, P2: Flashing:

During time delay $t_{\mbox{\tiny V2}}$ and for set up

assistance

Continuous: When relay P2 active (contact 21-24)

Fault indication

2 different faults are displayed with the LEDs.

1.) No measurement:

Without measuring voltage measurement is not possible - All 3 LEDs flash in sequence one after the other. The output contacts are in failure state.


2.) The BH 9097 measures negative load:

Possible reason: The unit measures reverse power or the current


connections are connected wrong.

- All 3 LEDs flash simultaneously.


Connection Diagrams




BH 9097.38/001



BH 9097.38/011



BH 9097.38



BH 9097.38/010

Technical Data

Input

Measuring voltage

Without auxiliary voltage 0.8 ... 1.1 x U_N Voltage range:

with auxiliary voltage, see setting ranges

 $300~\text{k}\Omega~...~500~\text{k}\Omega$ Input resistance:

Measuring current

Measuring range: See setting ranges

Nominal current [A]	40	24	8	2.4	0.8	0.24
Permissible current range						
(overload) [A] continuously:	0 40	0 40	0 16	08	0 2,4	0 1
1 min. (10 min. break):	150	150	20	16	3	1,5
20 s (10 min. break):	200	200	25	20	4	2
Input res. of current on i-k [m Ω]:	≤ 1	≤ 1	7	14	830	830

Upper range

Frequency range: 10 ... 400 Hz

(please see characteristics M7953)

Setting Ranges

P₁ und P₂ on absolute scale

Switch load range

for P1 and P2: Lower range

Measuring accuracy

 \pm 4 % (2 % on request) (in % of setting value):

Hysteresis

(in % of setting value): < 5 % Harmonic distortion: < 40 % Reaction time: < 50 ms

Switching delay t_{v1}/t_{v2} : Start-up time delay t_a : 0 ... 10 s (infinite variable) 0 ... 30 s (infinite variable)

Setting Ranges

Available variants	Measuring voltage U _N	Measuring current I _N [A]	selection of load range
1-phase			
Without auxiliary vo	ltage		
BH 9097.38/000	AC 230 V	0.0024 0.24	0.1 60 W
	AC 230 V	0.024 2.4	1 600 W
	AC 230 V	0.24 24	10 6000 W
With auxiliary voltag	е		
BH 9097.38/010	AC 35250 V	0.0024 0,24	0.1 60 W
	AC 35250 V	0.024 2,4	1 600 W
	AC 35250 V	0.24 24	10 6000 W
3-phase			
Without auxiliary vo	ltage		
BH 9097.38/001	3 AC 400 V	0.008 0,8	0.1 60 W
	3 AC 400 V	0.08 8	10 6000 W
	3 AC 400 V	0.4 40	0.1 30 kW
With auxiliary voltag	е		
BH 9097.38/011	3 AC 60 440 V	0.008 0,8	1 600 W
	3 AC 60 440 V	0.08 8	10 6000 W
	3 AC 100 760 V	0.4 40	0.1 52 kW

Auxiliary Circuit

Auxiliary voltage U_H Only for BH 9097.38/010,

BH 9097.38/011: AC 110 V (terminals A 1 - A 2),

AC 230 V (terminals A 1 - A 3),

DC 24 V

Voltage range: 0.8 ... 1.1 U_H 45 ... 400 Hz Frequency range of U_H:

Input current

AC 110 V: Approx. 30 mA AC 230 V: Approx. 15 mA DC 24 V: Approx. 50 mA

2 08.03.23 en / 702A

Technical Data

Output

Contacts: 1 changeover contact for P1

1 changeover contact for P2

1800 switching cycles / h

Thermal current I .:: 2 x 5 A

Switching capacity

to AC 15

IEC/EN 60947-5-1 NO contact: 3 A / AC 230 V NC contact: 1 A / AC 230 V IEC/EN 60947-5-1 To DC 13: 1 A / DC 24 V IEC/EN 60947-5-1

Electrical life

to AC 15 at 3 A, AC 230 V: 2x105 switching cycles IEC/EN 60947-5-1

Permissible switching

frequency:

Short circuit strength

max. fuse rating:

4 A gG / gL IEC/EN 60947-5-1 Mechanical life: 30 x 106 switching cycles

General Data

Operating mode: Continuous - 20 ... + 55 °C Temperature range: Clearance and creepage

distances

Rated impulse voltage / pollution degree:

EMC Electrostatic discharge: 8 kV (air) IEC/EN 61000-4-2 HF-irradiation: 10 V / m IEC/EN 61000-4-3 IEC/EN 61000-4-4 Fast transients: 2 kV

4 kV / 2

Surge voltages

between

wires for power supply: Between wire and ground:

HF-wire guided: Interference suppression: Degree of protection

Housing: IEC/EN 60529 Terminals: IP 20 IEC/EN 60529

1 kV

2 kV

10 V

Thermoplastic with V0 behaviour Housing: according to UL subject 94

Vibration resistance: Amplitude 0.35 mm

frequency 10 ... 55 Hz IEC/EN 60068-2-6 Climate resistance: 20 / 055 / 04 IEC/EN 60068-1 Terminal designation: EN 50005

Wire connection

Load terminals: 1 x 10 mm² solid or

1 x 6 mm² stranded wire with sleeve

Limit value class B

Control terminals: 1 x 4 mm² solid or 2 x 1.5 mm² stranded wire with sleeve

1 x 2,5 mm² stranded wire with sleeve

DIN 46228-1/-2/-3/-4

Wire fixing: Box terminals with self-lifting wire protection and Plus-minus terminal

screws M3.5

Mounting: DIN rail IEC/EN 60715 430 g Weight:

Dimensions

Width x height x depth: 45 x 84 x 121 mm

CCC-Data

Thermal current I,: 4 A

Switching capacity

3 A / AC 230 V to AC 15: IEC/EN 60947-5-1 To DC 13: 1 A / DC 24 V IEC/EN 60947-5-1



Technical data that is not stated in the CCC-Data, can be found in the technical data section.

Standard Type

BH 9097.38/001 3 AC 400 V 50 / 60 Hz t_a 30 s t_v 10 s

Article number: 0053944

3-phase, without auxiliary supply

1 changeover contact for P1 and Output:

1 changeover contact for P2

Nominal voltage U,: 3 AC 400 V Width: 45 mm

Variants

IEC 60664-1

IEC/EN 61000-4-5

IEC/EN 61000-4-5

IEC/EN 61000-4-6

EN 55011


BH 9097: With CCC-approval on request BH 9097.38/001: 3-phase without auxiliary supply BH 9097.38/011: 3-phase with auxiliary supply BH 9097.38/000: 1-phase without auxiliary supply BH 9097.38/010: 1-phase with auxiliary supply

With galvanically separated current path. BH 9097.38/1_ _: For applications with current transformers


grounded on the secondary side, current range limited to 25 A

BH 9097.38/801: Same as BH 9097.38/001, but with start-up time delay t_a = 0 ... 10 s


Ordering example for variants



Characteristics



Max. input current curve in relation to input frequency



Continuous current limit curve (Current over 2 contacts) M8367

3 08.03.23 en / 702A

Settings

 $\begin{array}{lll} \text{2 rotational switches for P}_1\text{:} & \text{Value P}_1\text{ (2 decades)} \\ \text{2 rotational switches for P}_2\text{:} & \text{Value P}_2\text{ (2 decades)} \\ \text{Potentiometer t}_{v_1}\text{:} & \text{Time delay for value P}_1\\ \text{Potentiometer t}_{v_2}\text{:} & \text{Time delay for value P}_2 \end{array}$

Potentiometer tall Start-up time delay after connection voltage
Test/Reset-Taste: Test function as setting assistance

Reset function when manual reset is

selected

Dip-switches:

x10 | x1 A | B

Selection of upper / lower load range Selection of closed or open circuit

Operation for output relays

 $P_{2 \text{ max.}} \mid P_{2 \text{ max}}$ $P_{1 \text{ max.}} \mid P_{1 \text{ min.}}$


2 MAX switching values (Overload with Pre-warning) or MAX and MIN switching value (Overload / Underload monitoring)

S1 ON I OFF: Manual / automatic reset for P₁ S2 ON I OFF: Manual / automatic reset for P₂


Connection

The device has to be connected according to the connection diagrams. The motor is connected to terminals L/i and T/k or L1/i and T1/k. The flow direction of the current has to be observed. On reverse power the unit gives a fault signal. The max continuous motor current is 40 A limited by the terminals. With higher currents a current transformer with 2,5 VA has to be used.

Set-up Procedure and Setting Instructions



Adjustemt example: response value: 2,5 kW



Response value = $25 \times 0.1 = 2.5 \text{ kW}$

The adjustment of the unit can be made without additional measuring equipment and calculations. Please make sure that the load values are in the permitted operating range of the unit. Based on the max permitted values the BH 9097 can be used for 48 kW 3-phase motors at 3 AC 690 V and 5.8 kW single phase motors at AC 230 V.

There are three methods to set up the unit:

Method 1:

If the absolute values of the actual required tripping points P_1 and P_2 are known, they can be set directly on the unit (2-digit setting of P_1 and P_2).

Method 2:


This method is recommended when it is possible to simulate the different load situations during set-up. In this case nothing has to be calculated. Turn the delay time for $\rm P_1$ and $\rm P_2$ to min. The motor runs in underload while the Pot 1 is turned until the output relay switches. The same has to be done for overload. Now the unit is set accurately. Now adjust the operate delay and the start-up delay to the required values.


Pressing the test / reset button during setup disables the switching of the output relays. The LEDs of P_1 and P_2 flash.

Method 3:


This method is the most simple one but not the most accurate. The operate delay is set to min. The motor is switched on and runs on nominal load. With both potentiometers the set points are searched by slowly turning the max. Pot from high to low value and the min. Pot from low to high value until the corresponding output relays switch. After that turn the Pot P_2 to the right (e.g. + 10 %) side and the Pot P_1 to the left (e.g. - 10 %) until the output relays reset. The unit is now set and responds if the load differs from the nominal value. Finally set the operate delay and start-up delay to the required values. The DIP switch should be set to $P_{1\,\text{min}}$ / $P_{2\,\text{max}}$.


4 08.03.23 en / 702A





Connection Examples with External Current Transformer






BH 9097.38/001

When using external CTs the adjusted value has to be multiplied with the transmission ratio (ü) of the CT. Switching value = Setting value (P1/P2) $\,x\,$ ü Note:

Example:

6 08.03.23 en / 702A



7

E. Dold & Söhne GmbH & Co. KG • D-78120 Furtwangen •	Bregstraße 18 • Phone +49 7723 654-0	• Fax +49 7723 654356

8