# **Monitoring Technique**

# **VARIMETER PRO Phase Monitor** BD 9080/003, BD 9080/004

# 0280060

# **Product Description**

The Phase monitor BD 9080 of the VARIMETER PRO series monitors over and undervoltage, asymmetry, power failure as well as wrong phase sequence at three-phase networks. The measurement is very simple and can be carried out without much wiring effort, as no separate auxiliary voltage is required. Early detection of impending failtures and preventive maintenance prevent costly damage and as a user you benefit from the operational safety and high availability of your system.

# **Function Diagram**



# **Circuit Diagram**



#### Translation DOLD of the original instructions

- According to IEC/EN 60255-1 •
- Monitoring of
  - Under- and overvoltage up to 3 AC 1000 V max.
  - Asymmetry Phase failure
  - Phase sequence
- Adjustable on delay 0.1 ... 30 s Without separate auxiliary voltage
- Start up delay t 30 s fixe
- One LED in each case for
- Operating voltage L1/L3

- Overvoltage U<sub>max</sub>. Undervoltage U<sub>min</sub> Asymmetry / Phase sequence / Power failure
- Contact position
- De-energized on trip
- 2 changeover contacts
- As option available with energized on trip
- Width: 45 mm

# **Approvals and Markings**



# Applications

For monitoring three-phase networks for undervoltage, overvoltage, phase sequence, asymmetry, power failure.

Indication		
1. Green LED L1 / L3:	Perm. on Flashes	<ul> <li>On, when supply connected</li> <li>Start up delay t on process</li> </ul>
2. Red LED U	Perm. on	- On, in event of overvoltage
2. Red LED U	Perm. on	- On, in event of undervoltage
2. Red LED $\Delta$ :	Perm. on	- On, in event of - Asymmetry
		- Power failure
2. Yellow LED:	Perm. on Flashes	<ul> <li>On, when output relay activated</li> <li>On delay t<sub>v</sub> on process</li> </ul>

# Notes

Measurement procedures:

Arithmetical mean value measurement over several half-waves of rectified phase voltages L1/L2 and L2/L3. Reference phase is L3. Networks with or without neutral can be monitored.

The start up delay only acts once after applying the operating voltage to L1 / L3.

# **Connection Terminals**

Terminal designation	Signal description	
L1, L2, L3	Connection phase voltage (L1, L2, L3)	
11, 12, 14	Indicator relay (1. C/O contact)	
21, 22, 24	Indicator relay (2. C/O contact)	

#### **Technical Data**

## Input Circuit

Nominal voltage U<sub>N</sub> L1 / L2 / L3:

3 AC 400 V

3 AC 750 V

0.8 ... 1.33 U<sub>N</sub>

U<sub>4</sub> ± 8 ... 20 %

 $\leq 0.08$  % / K

0.1 ... 30 s

2 A / AC 230 V

1 A / AC 230 V

1 A / DC 24 V

1 A / DC 24 V

4 A gG / gL

5 x 10<sup>5</sup> switch. cycles

10 x 10<sup>6</sup> switching cycles

Approx.  $120^{\circ} \pm 15^{\circ}$ 

2 changeover contacts

30 s fixe or alternatively  $t_a = t_v$ 6 A (see continuous current limit curve)

IEC/EN 60947-5-1

IEC/EN 60947-5-1

IEC/EN 60947-5-1

IEC/EN 60947-5-1

IEC/EN 60947-5-1

Approx. 900 / 150 ms

L1 approx. 4.3 mA

L2 approx. 0.3 mA L3 approx. 4.5 mA

50 / 60 Hz

45 ... 65 Hz

Min. voltage: 3 AC 320 V

Max. voltage: 3 AC 530 V

Min. voltage: 3 AC 600 V

Max. voltage: 3 AC 1000 V

(other voltages on request)

 $\leq 5 \% \text{ x } \text{U}_{\text{A}} (\text{U}_{\text{A}} = \text{Response value})$ 

Setting range: Nominal frequency of  $U_N$ : Frequency range of  $U_N$ : Power consumption with  $U_N$ :

Hysteresis: Asymmetry detection Voltage: Fault angle: Temperature influence:

## Output Circuit

Contacts: Response-/Release time: On delay t.: Start up delay t: Thermal current I ...: Switching capacity To AC 15 NO contact: NC contact: To DC 13 NO contact: NC contact: **Electrical life:** At 4 A, AC 230 V cos  $\varphi$  = 1: Short circuit strength Max. fuse rating: Mechanical life:

## **General Data**

Operating mode:	Continuous operation		
Temperature range			
Operation:	- 25 + 60 °C		
Storage:	- 40 + 85 °C		
Altitude:	< 2000 m		
Clearance and creepage			
distances			
Rated impulse voltage /			
pollution degree			
Measuring input / contact:	8 kV / 2	IEC 60664-1	
Contact / contact:	6 kV / 2	IEC 60664-1	
Overvoltage category:	111		
EMC			
Electrostatic discharge:	8 kV (air)	IEC/EN 61000-4-2	
HF irradiation:			
80 MHz 2.7 GHz:	10 V / m	IEC/EN 61000-4-3	
Langsame gedämpft			
schwingende Wellen			
Gegentaktspannung:	1 kV	IEC/EN 61000-4-18	
Gleichtaktspannung:	2.5 kV	IEC/EN 61000-4-18	
Fast transients:	2 kV	IEC/EN 61000-4-4	
Surge voltages			
Between			
wires for power supply:	1 kV	IEC/EN 61000-4-5	
Between wire and ground:	2 kV	IEC/EN 61000-4-5	
HF wire guided:	10 V	IEC/EN 61000-4-6	
Interference suppression:	Limit value class B	EN 55011	
Degree of protection:			
Housing:	IP 40	IEC/EN 60529	
Terminals:	IP 20	IEC/EN 60529	
Housing:	Thermoplastic with V0 behaviour		
	according to UL sub	oject 94	
Vibration resistance:	Amplitude 0.35 mm		
	Frequency 10 55 I	Hz, IEC/EN 60068-2-6	
Climate resistance:	20 / 060 / 04	IEC/EN 60068-1	

# **Technical Data**

Wire connection: Fixed screw terminals Cross section: Stripping length: Fixing torque: Wire fixing: Mounting: Weight: DIN 46228-1/-2/-3/-4 0.1 ... 4 mm² (AWG 28 - 12) solid or 0.1 ... 2.5 mm² (AWG 28 - 12) stranded wire with ferrules 10 mm 0.8 Nm Cross-head screw / M3,5 box terminals DIN rail IEC/EN 60715 325 g

## Dimensions

Width x height x depth:

#### **Classification to DIN EN 50155**

Vibration and shock resistance: Category 1, Class B IEC/EN 61373 Protective coating of the PCB: No

45 x 74 x 133 mm

#### Standard Type

BD 9080.12/003 3 AC 750 V Article number:	0.1 30 s 30 s 0068847
Output:	2 changeover contacts
<ul> <li>Nominal voltage U<sub>N</sub>:</li> </ul>	3 AC 750 V
<ul> <li>De-energized on trip</li> </ul>	
On delay t <sub>i</sub> :	0.1 30 s
<ul> <li>Start up delay t:</li> </ul>	30 s fixe
• Width:	45 mm
BD 9080.12/004 3 AC 400 V	0.1 30 s $t_a = t_v$
Article number:	0068849
Output:	2 changeover contacts
<ul> <li>Nominal voltage U<sub>N</sub>:</li> </ul>	3 AC 400 V
<ul> <li>De-energized on trip</li> </ul>	
Response delay t.:	0.1 30 s
<ul> <li>Start up delay t<sub>a</sub>:</li> </ul>	$t_a = t_v$
• Width:	45 mm

# Notes



- Disconnect the system and device from the power supply and ensure they remain disconnected during electrical installation.
- The voltage of the monitored voltage system is connected to terminals L1/L2/L3 Please observe sufficient distance to terminals of neighbour devices and to the grounded metal cabinet or box (min 0.5 cm).

### Ordering example





Continuous current limit curve



E. Dold & Söhne GmbH & Co. KG • D-78120 Furtwangen • Bregstraße 18 • Phone +49 7723 654-0 • Fax +49 7723 654356